

3.1.2 1131AG Status LED colour sequence during booting

(From,
1130AG Series AP_Hardware Inst. Guide_June 2006.pdf)

Minutes & Seconds after power-on	Colour	Meaning
0	Blue-green	Boot loader status. Initialize Flash file system.
20	Dark Green (actually chart has no entry for dark green so assume Green)	Boot loader status. DRAM memory test ok. (Not sure: I think AP Console shows IOS loading during this colour.)
46	Pink	Boot loader status. Flash memory test ok.
54	Light Green (Cisco doco calls this just Green)	Boot loader status. Starting Cisco IOS.
1m22s	Alternating green, red, and amber	Connecting to the controller. Note If the access point remains in this mode for more than five minutes, the access point is unable to find the controller. Ensure a DHCP server is available or that controller information is configured on the access point. MH: Sounds like LWAPP activity.
1m35s	Green	Association status. Normal operating condition, but no wireless client devices are associated with the unit.