

## EAP-TLS Configuration Guide v1.03

Written for AP 12.02T1 and above, ACS 3.1, 3.2, and 3.3, Windows 2000 and XP

This guide was written with the assumption that a Microsoft CA is being used. While it is possible to use a self-signed certificate as the server cert as of ACS 3.3, it is highly discouraged and not covered in this guide because the default expiration period of the self-signing cert is only one year and **cannot** be changed. This is fairly standard when it comes to server certs, but since the self-signed cert also acts as the root CA cert, this can mean installing the new cert on every client every year unless you do not check the "Validate Server Certificate" option. Since a real CA must be available to obtain the client certificates anyway, there is really no reason to employ self-signed certificates with EAP-TLS.

### Microsoft Certificate Services Installation

- A. Click start > Settings > Control Panel
- B. Inside the Control Panel, open Add/Remove Programs
- C. In Add/Remove Programs, select Add/Remove Windows Components
- D. Check "Certificate Services" and click Next (click yes to the IIS message)
- E. Select a Stand-alone (or Enterprise) root CA and click Next
- F. Give the CA a name\* (all the other boxes are optional) and click Next
- G. The database default is fine... click Next
- H. Finish

#### Note!!!

IIS must be installed before you install the CA.

\*Avoid giving the CA the same name as an ACS server. Doing so may cause EAP clients to fail authentication because they get confused when a root CA certificate is found with the same name as the server certificate. This problem is not unique to Cisco clients.

### ACS for Windows Certificate Setup

If you are configuring the ACS appliance, skip to step 6

#### 1. Create a Server Certificate

- A. From your ACS server, browse to the CA - [http://IP\\_of\\_CA\\_server/certsrv/](http://IP_of_CA_server/certsrv/)
- B. Select the "Request a certificate" option, and click Next
- C. Select Advanced request, and click Next
- D. Select "Submit a certificate request to this CA using a form", click Next
- E. Type something in the name (CN) box
- F. For Intended Purpose select "Server Authentication Certificate"\*
- G. Under Key Options:

- I. CSP = "Microsoft Base Cryptographic Provider v1.0"
- II. Key Size = 1024\*\*
- III. Check "Mark keys as Exportable"\*\*\*
- IV. Check "Use Local Machine Store" (Software ACS only)
- V. Leave everything else as default and click Submit

H. You should get a message that states "Your certificate request has been received..."

### **Note!!!**

\*If you are using the Enterprise CA, choose "Web Server" on the first drop down box.

\*\* The Windows 2003 Enterprise CA allows key sizes greater than 1024, but using a key larger than 1024 does not work with EAP. Authentication might appear to pass in ACS, but the client will just hang while attempting authentication.

\*\*\*Microsoft has changed the Web Server template with the release of the Windows 2003 Enterprise CA so that keys are no longer exportable and the option will be greyed out. Unfortunately, there are no other certificate templates supplied with certificate services that are for server authentication and give the ability to mark keys as exportable that will be available in the dropdown, so we have to create a new template that does so. Here are the steps:

1. Start > Run > certmpl.msc
2. Right-click Web Server template and choose Duplicate Template
3. Name the template something easy to identify like ACS.
4. Go to the Request Handling tab and check "Allow private key to be exported".
5. Click on the CSPs button and check "Microsoft Base Cryptographic Provider v1.0" and click OK.
6. All other options can be left at default.
7. Click Apply and OK.
8. Open the CA MMC snap-in.
9. Right-click Certificate Templates and choose New > Certificate Template to Issue.
10. Choose the new template you created and click OK.
11. Restart the CA.

The new template will be included in the Certificate Template dropdown.

Certificate services may also give a "Failed to create 'CertificateAuthority.Request' object" error when attempting to create a new certificate. Here are the steps to correct this:

1. Start > Administrative Tools > IIS
2. Expand Web Sites > Default Web Site
3. Right-click CertSrv and choose Properties

4. Click the Configuration button in the Application settings section of the Virtual Directory tab.
5. Go to the Options tab and check "Enable session state".
6. Everything else can be left alone.
7. Click OK and then OK.
8. Restart IIS.

It should also be noted that using a 2003 CA in a 2000 domain whose schema has not been prepared for 2003 compatibility with adprep/forestprep/domainprep will not work with EAP.

If your browser locks with a "Downloading ActiveX Control" message, you will need to run the fix discussed in the following URL:

<http://support.microsoft.com/default.aspx?scid=kb%3Ben-us%3B330389>

If the CSP field just says "Loading..." make sure you are not running a software firewall on the machine submitting the request. ZoneLabs' ZoneAlarm causes this pretty much every time. There may be other software that can cause this, but I have not identified any.

## **2. Approve the Certificate from the CA**

- A. Open the CA (click on Start > Programs > Administrative Tools > Certificate Authority)
- B. On the left, expand the certificate, then click "Pending Requests"
- C. Right-click on the certificate, select all tasks, then select "Issue"

## **3. Download the Server Certificate to the ACS Server**

- A. From your ACS server, browse to the CA - [http://IP\\_of\\_CA\\_server/certsrv/](http://IP_of_CA_server/certsrv/)
- B. Select "Check on a Pending Certificate", and click Next
- C. Select the certificate and click Next
- D. Click Install

## **4. Install the CA Certificate on the ACS Server**

(this step is not required if ACS and the CA are installed on the same server)

- A. From your ACS server, browse to the CA - [http://IP\\_of\\_CA\\_server/certsrv/](http://IP_of_CA_server/certsrv/)
- B. Select "Retrieve the CA certificate or certificate revocation list", and click Next
- C. Select "Base 64 encoded" and click "Download CA certificate"
- D. Click Open, and click "Install certificate"
- E. Click Next
- F. Select "Place all certificates in the following store" and click Browse
- G. Check the "Show physical stores" box
- H. Expand "Trusted root certification authorities", select Local Computer, and click Ok

I. Click Next, FINISH, and click Ok for "The import was successful" box

## 5. Setup ACS to use the Server Certificate

- A. On the ACS server click System Configuration on the left
- B. Select ACS Certificate Setup and then Install ACS certificate
- C. Select "Use certificate from storage"
- D. Type in the CN name (from step 2 e) and click Submit
- E. On the ACS server click system configuration on the left
- F. Select ACS Certificate Setup and then Edit Certificate Trust List
- G. Check the box for the CA (from step 1 f) and click Submit

### ACS Appliance Certificate Setup

**If you are configuring ACS for Windows, skip to step 12**

## 6. Create a Certificate Signing Request

- A. Go to System Configuration > ACS Certificate Setup > Generate Certificate Signing Request
- B. Enter a name in the Certificate subject field using the cn=name format
- C. Enter a name for the private key file\*
- D. Enter the private key password and confirm it
- E. Choose a key length of 1024\*\*
- F. Click Submit
- G. Copy the CSR output on the right-hand side for submittal to the CA

\*Note that the path to the private key will be cached in this field so if "submit" is pressed a second time after the CSR is created the private key will be overwritten and will not match the original CSR. This will result in a "private key does not match" error when you attempt to install the server certificate.

\*\*while ACS can generate key sizes greater than 1024, using a key larger than 1024 does not work with EAP. Authentication might appear to pass in ACS, but the client will just hang while attempting authentication.

## 7. Create a Server Certificate using your CSR

- A. From your FTP server, browse to the CA - [http://IP\\_of\\_CA\\_server/certsrv/](http://IP_of_CA_server/certsrv/)
- B. Select the "Request a certificate" option, and click Next
- C. Select Advanced request, and click Next
- D. Select "Submit a certificate request using a base64 encoded PKCS #10 file or a renewal request using a base64 encoded PKCS #7 file"
- E. Paste the output from step 6 G into the Base64 Encoded Certificate Request field and click Submit.
- F. Click "Download CA certificate"

- G. Click “Save”, name the certificate something useful, and save it to your FTP directory

## **8. Download CA Certificate to your FTP Server\***

- A. From your FTP server, browse to the CA - `http://IP_of_CA_server/certsrv/`
- B. Select "Retrieve the CA certificate or certificate revocation list", and click Next
- C. Select "Base 64 encoded" and click "Download CA certificate"
- D. Click “Save”, name the certificate something useful, and save it to your FTP directory

## **9. Install CA Certificate on your Appliance\***

- A. Go to System Configuration > ACS Certificate Setup > ACS Certification Authority Setup
- B. Click “Download CA certificate file”
- C. Type the IP address or hostname of the FTP server in the FTP Server field
- D. Type a valid username that Cisco Secure ACS can use to access the FTP server in the Login field
- E. Type the above user's password in the Password field
- F. Type the relative path from the FTP server root directory to the directory containing the CA certificate file in the Remote FTP Directory field
- G. Type the name of the CA certificate file in the Remote FTP File Name field
- H. Click Submit
- I. Verify the filename in the field and click Submit
- J. Restart the ACS services in System Configuration > Service Control

\*Skipping these steps will result in either not being able to enable EAP-TLS in step 12 and getting an error that the server certificate is not installed even though it is or getting an “EAP type not configured” failure in failed attempts even though the EAP type IS configured.

Also note that, if your server cert was created using an intermediate CA, you will need to repeat these steps for every CA in the chain between the root CA and the server cert (including the root CA cert, of course).

## **10. Install Server Certificate on your Appliance**

- A. Go to System Configuration > ACS Certificate Setup
- B. Click Install ACS Certificate
- C. Select the Read certificate from file option and then click the Download certificate file link
- D. Type the IP address or hostname of the FTP server in the FTP Server field
- E. Type a valid username that Cisco Secure ACS can use to access the FTP server in the Login field

- F. Type the above user's password in the Password field
- G. Type the relative path from the FTP server root directory to the directory containing the server certificate file in the Remote FTP Directory field
- H. Type the name of the server certificate file in the Remote FTP File Name field
- I. Click Submit
- J. Enter the path to the private key from step 6 C
- K. Enter the password for the private key from step 6 D
- L. Click Submit

## 12. Configure Global Authentication Settings

- A. On the ACS server click System Configuration on the left
- B. Click Global Authentication Setup
- C. Check Allow EAP-TLS
- D. Select one or more certificate verification options (selecting all methods will cause ACS to try each method in sequence until a successful verification occurs or until the last method fails.)
- E. Click Submit and Restart

## 13. Setup the AP on the ACS

- A. On the ACS server click Network Configuration on the left.
- B. To add a AAA client click Add Entry
- C. Fill in the boxes:
  - I. AAA Client IP Address = "IP\_of\_your\_AP"
  - II. Key = Make up a key, and make sure this matches on the AP shared secret.
  - III. Authenticate Using = RADIUS (Cisco Aironet)
  - IV. Submit and Restart

### Note!!!

I didn't change any of the defaults on the AAA client setup.

## 14. Configure the AP

---

---

With VxWorks:

---

---

- A. Open the AP and go to Setup > Security > Authentication Server
  - I. Enter the ACS IP address
  - II. Enter the shared secret (Must match the 'KEY' in ACS)
  - III. Use server for: check "EAP Authentication"
  - IV. The default should work for everything else... click Ok
- B. Go to Setup > Security > Radio Data Encryption
  - I. For Accept Authentication Type check "Open" and "Network-EAP"
  - II. For Require EAP check "Open"

- III. If you are not using broadcast key rotation, set WEP key 1 and select 128bit
- IV. Change Use of Data Encryption by Stations to "full Encryption"  
(if you can't change the use of data encryption Click apply first)
- V. Click Ok

---

---

With IOS AP web interface:

---

---

- A. Open the AP and go to Security > Server Manager
  - I. Choose RADIUS from the Current Server List dropdown
  - II. Enter the ACS IP address
  - III. Enter the shared secret (Must match the 'KEY' in ACS)
  - IV. Use server for: check "EAP Authentication"
  - V. Click OK on the warning dialogue and then click Apply
  
- B. Go To Security > SSID Manager\*
  - I. Choose the SSID from the Current SSID List or enter a new SSID in the SSID field
  - II. Check Open Authentication and choose "with EAP" from the dropdown
  - III. Check Network EAP
  - IV. All other values can be left at default and click Apply
  
- C. Go to Security > Encryption Manager\*
  - I. Place the radio button in WEP Encryption and choose Mandatory from the dropdown
  - II. Place the radio button in Encryption Key 1, enter the key in the field
  - III. Choose 128 bit from the Key Size dropdown
  - IV. Click Apply

**Note!!!**

The network-eap is required if you are installing the ACU.

If you are using broadcast key rotation, you don't need to set a key as the key should already be set. If it not, go to Setup > Radio Advance and set a value for the broadcast key rotation. You probably don't need to set this any lower then 5 minutes (300 secs). Once the value is set, click OK and go back into the radio data encryption page.

\*Configuration will differ if using WPA. See WPA Key Management supplement at the end of this document for details.

## 15. Download and Install the Root CA Certificate for the Client

- A. From the client PC, browse to the CA - [http://IP\\_of\\_CA\\_server/certsrv/](http://IP_of_CA_server/certsrv/)
- B. Select Retrieve a CA certificate and click Next
- C. Select Base64 Encoding and "Download CA certificate"
- D. Click open and click "Install Certificate"
- E. Click Next
- F. Select "Place all certificates in the following store" and then click Browse
- G. Check the "Show physical stores" box
- H. Expand "Trusted root certification authorities", select local computer, and click Ok.
- I. Click Next, FINISH, and click Ok for "The import was successful" box

### Note!!!

This step is REQUIRED for EACH client for EAP-TLS to work on that client.

Steps 16-18 are REQUIRED for **EACH USER** for EAP-TLS to work.

## 16. Create Client Certificate

---

---

### Enterprise CA

---

---

- A. From the client's user account, browse to the CA - [http://IP\\_of\\_CA\\_server/certsrv/](http://IP_of_CA_server/certsrv/)
- B. Select the "Request a certificate" option, and click Next
- C. Select Advanced request, and click Next
- D. Select "Submit a certificate request to this CA using a form", click Next
- E. Choose "User" in the Certificate Template dropdown
- F. Under Key Options:
  - I. CSP = "Microsoft Base Cryptographic Provider v1.0"
  - II. Key Size = 1024
  - III. Leave everything else as default and click Submit
- G. You should get a message that states "Your certificate request has been received..."

---

---

### Standalone CA

---

---

- A. From the client's user account, browse to the CA - [http://IP\\_of\\_CA\\_server/certsrv/](http://IP_of_CA_server/certsrv/)
- B. Select the "Request a certificate" option, and click Next
- C. Select Advanced request, and click Next
- D. Select "Submit a certificate request to this CA using a form", click Next
- E. Type the username in the CN field (must match username in the authentication database)

F. For Intended Purpose select "Client Authentication Certificate"

G. Under Key Options:

I. CSP = "Microsoft Base Cryptographic Provider v1.0"

II. Key Size = 1024

III. Leave everything else as default and click Submit

H. You should get a message that states "Your certificate request has been received..."

## 17. Approve Client Certificate from the CA

A. Open the CA (click on Start > Programs > Administrative Tools > Certificate Authority)

B. On the left, expand the certificate and then click "Pending Requests"

C. Right-click on the certificate, select all tasks, then select "Issue"

## 18. Install the Client Certificate on the Client PC

A. From the clients user account, browse to the CA -

[http://IP\\_of\\_CA\\_server/certsrv/](http://IP_of_CA_server/certsrv/)

B. Select "Check on a Pending Certificate", and click Next

C. Select the certificate and click Next

D. Click Install

### **Note!!!**

You can verify the certificate installation by going to Microsoft Internet Explorer, choose Tools > Internet Options > Content > Certificates; a certificate with the name of the logged-in user ID/username should be present.

## 19. Setup the Client for EAP-TLS

A. Open Network Connections on the control panel (click Start -> Control Panel)

B. Right-click the wireless network and select Properties

C. On the wireless network tab, make sure "use windows to configure..." is checked

D. If you see the SSID in the list click Configure. If NOT, click Add.

E. Put in the SSID and check the WEP and "Key is provided for me automatically" boxes

F. Select the authentication tab, make sure "enable network-access control using..." is checked

G. For EAP type select "Smart Card or Other Certificate" and click Properties

H. Place the radio button in "Use certificate on this computer"

I. Place a check in "Use simple certificate selection"

J. Under "Trusted root certificate" check the box for the CA

I. click Ok, Ok, and OK

**Note!!!**

If there is no Authentication tab - the 802.1X service is installed in a disabled state. To solve this, you must enable the Wireless Configuration service in the list of services:

- I. Right-click My Computer, and then click Manage.
- II. Click Services and Applications, and then click Services.
- III. Set the Startup value for the service to Automatic, and then start the service.

If the Authentication tab is present but is unavailable, this indicates that the network adapter driver does not support 802.1x correctly. See below URL for compatibility:

<http://support.microsoft.com/default.aspx?kbid=313664>

## Machine Authentication Supplement

EAP-TLS Machine Authentication REQUIRES both Active Directory and an Enterprise root CA. To acquire a certificate for EAP-TLS machine authentication, the computer must have connectivity to the Enterprise CA either through a wired connection or through the wireless connection with 802.1x security disabled. Note that this is the ONLY way to obtain a valid machine certificate (with "Machine" in the "Certificate Template" field). Once completed, The machine certificate will be installed in the "Certificates (Local Computer)" > Personal > Certificates folder when viewed in the Certificates (Local Computer) MMC snap-in and will have the fully qualified AD machine name in the Subject and SAN fields. A certificate that bears the name of the computer but was not created as described below is NOT a true machine certificate (with "Machine" in the Certificate Template field) and will not be used for machine authentication but rather will be seen by the OS as a normal user certificate.

### 1. Setup ACS to Allow Machine Authentication

- A. Go to External User Databases > Database Configuration
- B. Click Windows Database and then Configure
- C. Place a check in "Enable EAP-TLS machine authentication"
- D. Submit

### 2. Configure the domain for certificate auto-enrollment

- A. Open the Users and Computers MMC snap-in on a domain controller
- B. Right-click the domain entry and choose 'Properties'
- C. Go to the 'Group Policy' tab, select the 'Default Domain Policy' and click Edit
- D. Go to 'Computer Configuration' > 'Windows Settings' > 'Security Settings' > 'Public Key Policies'
- E. Right-click 'Automatic Certificate Request Settings' and choose 'New' > 'Automatic Certificate Request...' and click Next

- F. Highlight 'Computer' and click Next
- G. Check the enterprise CA and click Next and then Finish

### 3. Setup the Client for Machine Authentication

---

---

#### Join the Domain\*

---

---

- A. Log into Windows with an account that has administrator privileges
- B. Right-click on My Computer and choose Properties
- C. Select the Computer Name tab and click Change
- D. Enter the host-name in the Computer name field
- E. Select Domain, enter the name of the domain, and Click OK
- F. To join the domain, a login dialog will be displayed. Login with an account that has permission to join the domain.
- G. Once the computer has successfully joined the domain, restart the computer.  
The machine will be a member of the domain, and have a certificate for the CA and a machine certificate installed

#### **Note!!!**

\*If the client joined the domain prior to configuring auto-enrollment, the certificate should be issued to the machine the next time you reboot the computer after auto-enrollment is configured without having to re-join the computer to the domain.

---

---

#### Setup EAP-TLS supplicant for machine authentication

---

---

- A. Open Network Connections on the control panel (click Start > Control Panel)
- B. Right-click the network connection and select Properties
- C. Select authentication tab and check "Authenticate as computer...."

### **WPA Key Management Supplement**

Written for IOS AP 12.02(13)JA1, ACS 3.2, and XP SP1 with WPA hotfix

#### **Note!!!**

According to the following documentation (close to the bottom), Windows 2000 clients do not natively support WPA key management and you must use the vendor's client software in order to get this support:

<http://support.microsoft.com/?kbid=815485>

Unfortunately, the Cisco ACU does not support WPA key management for host-based EAP (EAP-TLS and PEAP) at this time and you must install a third party client such as the Funk Odyssey client or Meetinghouse AEGIS client. Further information on WPA support for Cisco products can be found here:

[http://www.cisco.com/univercd/cc/td/doc/product/wireless/airo\\_350/350cards/windows/wizardrn/wiz12new.htm#82435](http://www.cisco.com/univercd/cc/td/doc/product/wireless/airo_350/350cards/windows/wizardrn/wiz12new.htm#82435)

The above information is true for Windows Mobile 2003 (Pocket PC) clients as well.

**WPA key management is basically the same with only the following changes:**

### **1. Configure the AP**

- A. Go to Security > Encryption Manager
  - I. Place the radio button in WEP Cipher and choose TKIP from the dropdown
  - II. Click Apply
  
- B. Go To Security > SSID Manager
  - I. Choose the SSID from the Current SSID List or enter a new SSID in the SSID field
  - II. Check Open Authentication and choose "with EAP" from the dropdown
  - III. Check Network EAP
  - IV. Under "Authenticated Key Management" select "Mandatory" from the drop down menu and click "WPA"
  - V. Click Apply

### **2. Setup the XP Client for EAP-TLS and WPA**

- A. Open Network Connections on the control panel (click Start -> Control Panel)
- B. Right-click the wireless network and select Properties
- C. On the wireless network tab, make sure "use windows to configure..." is checked
- D. If you see the SSID in the list click Configure. If NOT, click Add.
- E. Put in the SSID and choose "WPA" for Network Authentication and TKIP for Data Encryption
- F. Select authentication tab, make sure "enable network-access control using..." is checked
- G. For EAP type select "Smart Card or Other Certificate" and click Properties
- H. Place the radio button in "Use certificate on this computer"
- I. Place a check in "Use simple certificate selection"
- J. Under "Trusted root certificate" check the box for the CA
- I. click Ok, Ok, and OK